

FSA Remote Touch Screen

Quick Reference

HISTORY

VIEW All – Display all system activations in chronological order

TICKETS – Show CAD dispatches only

MESSAGES – Search general announcements and manual activations only

SEARCH ALARM TYPE – Use a drop down list to search alarm types

SEARCH ID – Search by full CAD incident number

SEARCH DATE – Search by a date range

PRINT – Print a ticket for the message on the screen

CLEAN SCREEN – Lock the screen for 15 seconds to clean it

MAP – Display a map of the incident on the screen

HOME – Return to the home screen

Arrow Buttons – Scroll through the messages/incidents

MICROPHONE

Touch Screen Mic is used to talk to a citizen at the front door when the **TALK** button is activated. Conversation will only be delivered to the speaker above the Remote Touch Screen. The mic can be used as the station PA mic all other times.

CAMERA/DOORBELL

HOME – Turn off the camera and the outside doorbell speaker. Always use the home button to turn off the doorbell when finished.

CAMERA – Anytime the *front* doorbell is rung, the camera view appears on the Remote Touch Screen. It can also be turned on and off by touching the **CAMERA** button.

TALK – Touch the TALK button if there is a desire to talk to the citizen at the front door with the speaker mic, otherwise touch **HOME** to turn the doorbell off.

An alternate option to turn off the doorbell announcement is to push the red **EMERGENCY** button next the front door.

If the doorbell is not acknowledged after 90 seconds, the camera view and speaker will go to the ECC dispatcher. This is to assist a citizen who might need help, but the station is empty.

SYSTEM TROUBLE For general service requests or to order printer paper, complete a TSR on MCFRS Quicklinks. For a mission critical system outage, call 240-777-2233.

HISTORY SCREEN

CAMERA SCREEN

FSA Remote Touch Screen

Quick Reference

HOME SCREEN

Any system activation will display on the screen.

CAMERA – Turn the camera display on

HOME – Turn the camera display off

HISTORY – Go to the History Screen

PRINT – Print a ticket for the current incident displayed

CLEAN SCREEN - Lock the screen for 15 seconds to clean it

MAP – Display a map for the current incident on screen

MANUAL ACTIVATION

Touch one or more unit to be activated

Touch the **MANUAL** button

The system will announce “MANUAL ACTIVATION [unit]” two times

System lights and monitors will be active for 2 minutes



DAY / NIGHT AUDIO LEVELS

The audio level to all zones is decreased at a specified time each evening when the ambient background noise levels are lower. Every morning the audio levels are restored to full volume. Note: the night audio level in each zone is configured and set independently.

TURN OUT TIMERS



The timer activates at the moment of dispatch, counting up from zero to two minutes. This is a local timer only and does not communicate with any other system. If multiple calls are dispatched back to back the timer will finish the count down on the first call and then restart with the remaining time on the second call.

VOLUME CONTROLS The 7A/FSA volume control typically cannot be turned down to zero. The 7A radio is intended to be heard at all times. The Scanner volume controls the scanner, weather radio and PA. There is a scanner volume control in almost every room in order to adjust the level of the scanner to a lower level.

HOME SCREEN

PURVIS SYSTEMS
FIRE STATION ALERTING SYSTEM
11:10

HOME	CAMERA	Incident # 636166191549069333			
HISTORY	PRINT	Address			
CLEAN SCREEN	LOGIN	2387 MAIN ST			
MAP		DRIVE BAY 2			
		Green Gas Station			
		Cross Street Constitution st / Hope St			
		Box Area 1676			
		Call Type			
		BUILDING FIRE W/ HAZMAT			
		57D1G			
		Units			
		W717 AT731 E731 M731			
		Date / Time			
		12/06/2016 11:10:53			
		ENGINE	TRUCK	SPECIAL	BLS
		ALS			
		MANUAL			

FLAT PANEL MONITORS

Monitors display incident information for 2 minutes after the call is dispatched.

The screens will toggle between incidents if multiple incidents are dispatched back to back.

Screen savers – An active incident list and current weather information

ADDRESS

BOX AREA

RESPONDING UNITS

1/1
INCIDENT TYPE
time

COLORED LIGHTS (Towers, Displays)

The color indicator lights illuminate when those specific units have been dispatched. For example, when a RED light is illuminated, the engine has been dispatched. For the tower lights, the order from top to bottom is as follows:

RED – Engine, YELLOW – Truck, GREEN – Tankers, Squads, Teams, BLUE – BLS Ambulance, WHITE – Medic Unit

ENGINE

TRUCK

SPECIAL

BLS

ALS